









S343901 Replacement Part - Royale Robooter
Joystick Assembly For E40/E60
-A/E60-Pro-A Each




S343903 Replacement Part - Royale Robooter
Joystick Knob For E40/E60
-A/E60-Pro-A/E80 Each




S343904 Replacement Part - Royale Robooter
Joystick Veneer Upholstery Cover RHS/LHS
For E40/E60-A/E60-Pro-A Each




S343870 Replacement Part - Royale Robooter
Armrest w/Light Assembly For E40/E60
-A/E60-Pro-A/E80 Each




S343859 Replacement Part - Royale Robooter
Armrest Assembly LHS For E40
(Doesn't Include Top Cover) Each




S343861 Replacement Part - Royale Robooter
Armrest Assembly RHS For E40
(Doesn't Include Top Cover) Each




S343869 Replacement Part - Royale Robooter
Armrest Top Cover Only For E40/E60
-A/E60-Pro-A Each



S343863 Replacement Part - Royale Robooter
Armrest LHS Cover For E40 Each




S343866 Replacement Part - Royale Robooter
Armrest RHS Cover For E40 Each




S343864 Replacement Part - Royale Robooter
Armrest LHS Round Cap Cover For
E40/E80 Each




S343867 Replacement Part - Royale Robooter
Armrest RHS Round Cap Cover For
E40/E80 Each




S343873 Replacement Part - Royale Robooter
Backrest Assembly (Without Backpack)
For E40 Each




S343840 Replacement Accessory - Royale
Robooter Backpack For E40/E60
-A/E60-Pro-A Each




S343884 Replacement Part - Royale Robooter
Folding Lever Mechanism Assembly
For E40/E60-A/E60-Pro-A/E80 Each




S343937 Replacement Part - Royale Robooter
Seat Cushion For E40/E60
-A/E60-Pro-A Each




S343936 Replacement Part - Royale Robooter
Seat Canvas Assembly For E40/E60
-A/E60-Pro-A/E80 Each




S343844 Replacement Accessory - Royale Robooter Seat Belt Assembly For E40/E60-A/E60-Pro-A/E80 Each




S343845 Replacement Accessory - Royale Robooter Storage Basket For E40/E80 Each



S343887 Replacement Part - Royale Robooter Footplate Assembly For E40 Each




S343853 Replacement Part - Royale Robooter 8" PU Front Wheel Assembly For E40/E80 Each




S343894 Replacement Part - Royale Robooter Front Fork Assembly For E40/E80 Each




S343896 Replacement Part - Royale Robooter Front Fork RHS/LHS Cap Cover White For E40 (Pair)




S343921 Replacement Part - Royale Robooter Pneumatic Rear 10" Tyre Assembly LHS For E40/E60-A Each




S343923 Replacement Part - Royale Robooter Pneumatic Rear 10" Tyre Assembly RHS For E40/E60-A Each




S344207 Replacement Part - Royale Robooter
Pneumatic Rear 10" Tube Only
For E40/E60-A Each




S344210 Replacement Part - Royale Robooter
Pneumatic Rear 10" Tyre Only
For E40/E60-A Each




S343934 Replacement Part - Royale Robooter
Rear Tyre Hub Cap Cover White
For E40 (Pair)




S343910 Replacement Part - Royale Robooter
Motor Assembly LHS For E40 Each




S343913 Replacement Part - Royale Robooter
Motor Assembly RHS For E40 Each




S343851 Replacement Part - Royale Robooter
24V20AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343852 Replacement Part - Royale Robooter
24V25AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343850 Replacement Part - Royale Robooter
24V12AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343878 Replacement Part - Royale Robooter
Battery Locking Clip For E40/E60
-A/E60-Pro-A/E80 (Pair)




S344349 Replacement Charger - Royale
Robooter Universal 3AH Charger
For E40/E80 Each




S343879 Replacement Part - Royale Robooter
Charging Cable For AU Wall Socket
For E40/E60-A/E60-Pro-A/E80 Each




S343928 Replacement Part - Royale Robooter
Rear Black Shroud Assembly For
E40/E80 Each




S343932 Replacement Part - Royale Robooter
Rear Manual Drive Locking Lever Red
For E40/E60-A/E60-Pro-A/E80 Each




S343856 Replacement Part - Royale Robooter
Anti-Tip Bar (Without Wheel)
For E40/E60-A Each




S343848 Replacement Part - Royale Robooter
2" Anti-Tip Wheel w/Screws For
E40/E60-A/E60-Pro-A Each




S343885 Replacement Part - Royale Robooter
Folding Roller Wheel LHS For
E40/E60-A/E60-Pro-A/E80 Each




S343886 Replacement Part - Royale Robooter
Folding Roller Wheel RHS For
E40/E60-A/E60-Pro-A/E80 Each




S343880 Replacement Part - Royale Robooter
Control Box For E40/E60
-A/E60-Pro-A Each




S343882 Replacement Part - Royale Robooter
Control Box Mounting Plate For
E40/E60-A/E60-Pro-A Each




S343906 Replacement Part - Royale Robooter
M3x8 Screws For E40/E60-A/E60
-Pro-A/E80 (Pack of 6)



S343935 Replacement Part - Royale Robooter
Rear Tyre Screw and Washer
Set For E40 (Pack of 3)



S343907 Replacement Part - Royale Robooter
M4x12 Screws For E40/E60
-A/E60-Pro-A/E80 Each(Pack of 8)



S343908 Replacement Part - Royale Robooter
M4x16 Screws For E40/E60
-A/E60-Pro-A/E80 (Pack of 6)

S343877 Replacement Part - Royale Robooter Battery Connection Cable For E40/E60-A/E60-Pro-A/E80 Each

S343876 Replacement Part - Royale Robooter Backrest Folding Component For E40/E80 Each

S343941 Replacement Part - Royale Robooter Upper and Lower Control Connection Cable RHS/LHS Dual Control Assembly For E40/E60-A/E60-Pro-A/E80 Each
